FIGURE 1

FIGURE 2

Begin

Apply test signals to the network — 40

Adjust attenuator to adjust noise level — 42

Adjust attenuator to adjust receiver input power — 43

Receive test signals at the receiver — 44

Compare received signals to original signals — 46

no

Done? — 48

yes

Return